








<b>KIR-Rohre</b>		<b>1.1.1</b>		
	KIR-Rohr	-20	1005	<b>1.25</b>
		25	1006	<b>1.70</b>
		32	1007	<b>2.75</b>
		40	1008	<b>3.95</b>
		50	1009	<b>5.90</b>
		63	1010	<b>8.75</b>


<b>KIR-Bögen</b>		<b>1.1.1</b>		
	KIR-Bogen steckbar	-20	1138	<b>1.90</b>
		25	1139	<b>2.55</b>
		32	1140	<b>3.40</b>
		40	1147	<b>4.55</b>
		50	1148	<b>9.15</b>
	63	1149	<b>16.55</b>	
	KIR-Bogen -25 m Biegefeder erstellen	45-90°	1018	


<b>KIR-Rohre hf lichtgr</b>		<b>1.1.1</b>		
	KIR-Rohr hf lichtgr	-20	125 140	<b>3.10</b>
		25	125 141	<b>4.—</b>
		32	125 142	<b>6.30</b>
		40	125 143	<b>7.85</b>
		50	125 144	<b>11.15</b>
		63	125 145	<b>22.60</b>


<b>KIR-Rohre hf sw</b>		<b>1.1.1</b>		
	KIR-Rohr hf sw UV-stabil	20	1577	<b>7.55</b>
		25	1578	<b>9.95</b>
		32	1579	<b>14.75</b>
		40	1580	<b>19.90</b>



<b>Klemmbriden sw</b>		<b>1.1.2</b>		
	Klemmbride sw	20	1595	<b>1.60</b>
		25	1596	<b>1.95</b>
		32	1597	<b>2.50</b>
		40	1598	<b>3.70</b>


<b>KRH-Rohre</b>		<b>1.1.2</b>		
	KRH-Rohr	20	1031	<b>2.60</b>
		25	1032	<b>3.80</b>
		32	1033	<b>5.90</b>
		40	1034	<b>8.85</b>
		50	1035	<b>12.65</b>
		63	1036	<b>19.95</b>


	KRH-Bogen m Fön erstellen	45-90°	1028	
------------------------------------------------------------------------------------	---------------------------	--------	------	--


<b>Rohrschellen Clic</b>		<b>1.1.2</b>		
	Rohrschelle Clic	-20	126 274	<b>-90</b>
		25	126 275	<b>1.20</b>
		32	126 276	<b>1.35</b>
		40	126 277	<b>2.—</b>
		50	126 278	<b>2.25</b>
		63	126 279	<b>3.20</b>


<b>Al-Rohre</b>		<b>1.1.3</b>		
	Al-Rohr	-20	155 001	<b>3.55</b>
		25	155 002	<b>5.25</b>
		32	155 003	<b>6.80</b>
		40	155 004	<b>9.25</b>
		50	155 005	<b>11.95</b>
		63	155 006	<b>16.90</b>


<b>Al-Bögen</b>		<b>1.1.3</b>		
	Al-Bogen steckbar	-20	125 047	<b>8.—</b>
		25	125 048	<b>10.35</b>
		32	125 049	<b>13.30</b>
		40	125 050	<b>21.55</b>
		50	125 051	<b>44.90</b>
		63	125 052	<b>62.20</b>
	Al-Bogen -25 m Biegefeder erstellen	45-90°	1048	

<b>Al-Klemmbriden</b>		<b>1.1.3</b>		
	Al-Klemmbride	-20	126 141	<b>2.60</b>
		25	126 142	<b>2.80</b>
		32	126 143	<b>3.10</b>
		40	126 144	<b>3.40</b>
		50	126 145	<b>4.—</b>
		63	126 146	<b>4.30</b>

<b>Schnellverleger</b>		<b>1.1.3</b>		
	Schnellverleger Al o Gegenwanne	16/20	1241	<b>1.95</b>
		25	1242	<b>2.35</b>
		32	1243	<b>2.70</b>
		40	1244	<b>3.65</b>
		50	1245	<b>4.55</b>
		63	1246	<b>8.90</b>

<b>ERZ-Rohre</b>		<b>1.1.4</b>		
	ERZ-Rohr	-20	1021	<b>9.70</b>
		25	1022	<b>12.55</b>
		32	1023	<b>16.20</b>
		40	1024	<b>20.85</b>
		50	1025	<b>26.70</b>
		63	1026	<b>35.70</b>

<b>ERZ-Bögen</b>		<b>1.1.4</b>		
	ERZ-Bogen	-20	1131	<b>6.70</b>
		25	1132	<b>7.85</b>
		32	1133	<b>10.65</b>
		40	1134	<b>16.80</b>
		50	1135	<b>34.30</b>
		63	1136	<b>48.50</b>

<b>Rohrschellen verz</b>		<b>1.1.4</b>		
	Rohrschelle verz M6	-20	1201	<b>3.35</b>
		25	1202	<b>3.50</b>
		32	1203	<b>3.60</b>
		40	1204	<b>3.80</b>
		50	1205	<b>4.15</b>
		63	1206	<b>4.75</b>

	Gewindestange verz M6	-250	1200	<b>-75</b>
-------------------------------------------------------------------------------------	-----------------------	------	------	------------